

Product	Model	Data	Issue Date
EZ-STIK #3 Trowelable Sealant	All	Installation Instructions	March 2008

INSTALLATION INSTRUCTIONS FOR TROWELABLE #3 EZ-STIK AS A PROTECTIVE COATING

1.

The concrete surface the #3 EZ-STIK is to be applied to must be clean and dry. Any dirt and/or mud adhering to the surface must be removed. The surface must be dry for the #3 EZ-STIK to adhere and bond to the concrete.

2.

The #3 EZ-STIK should be applied with a smooth-edge trowel. The #3 EZ-STIK should be applied a minimum of 1/4" thick. The surface to be protected must be totally covered with no surface showing through the #3 EZ-STIK.

3.

The structure should not be backfilled for a minimum of 20 minutes after coating with the #3 EZ-STIK. This allows the solvents to dispense throughout the #3 EZ-STIK.

Should you need further information or have questions concerning these installation instructions, please contact our Customer Service Department at 800-348-7325.

Press-Seal Gasket believes all information is accurate as of its publication date. Information and specifications are subject to change without notice. Press-Seal Gasket is not responsible for inadvertent errors. Copyright 2008.



PRESS-SEAL GASKET CORPORATION

Fort Wayne, Indiana USA

Providing Products and Services That Protect Our Planet's Clean Water Supply

800-348-7325 Fax (260) 436-1908

email: sales@press-seal.com

web: www.press-seal.com

